

ProPay® Chip Card Reader Device Compatibility List



Device Manufacturer	Device Name
Apple	iPad Pro
Apple	iPad Pro 10.5-inch Wi-Fi
Apple	iPad Pro 12.9-inch Wi-Fi
Apple	iPad Wi-Fi
Apple	iPhone 7
Apple	iPhone 7 (Japan version)
Apple	iPhone 7 Plus
Apple	iPhone 8
Apple	iPhone 8 Plus
GIONEE	M6
Google	Pixel
HTC	M10u
Huawei	Honor 5A
HUAWEI	P10
HUAWEI	Magic
HUAWEI	G9
HUAWEI	Mate9
HUAWEI	8
HUAWEI	5A
HUAWEI	5C

HUAWEI	9
HUAWEI	V9
LENOVO	VIBE P2
LENOVO	Zuk Edge
Letv	MAX2
Letv	Pro2
Letv	Pro3
LG	V10
LG	V20
MEIZU	Pro6 Plus
MEIZU	MX6
MEIZU	PRO6S
MEIZU	E
MEIZU	Note5
MOTOROLA	Z
MOTOROLA	Z Play
MOTOROLA	Z2PLAY
ONEPLUS	5
OPPO	R11
OPPO	R9S
Samsung	Galaxy J2 Pro
Samsung	Galaxy J5 (2016)
Samsung	C9PRO

Samsung	Galaxy Note7
---------	--------------

Samsung	Galaxy Note8
---------	--------------

Samsung	Galaxy S7
---------	-----------

Samsung	Galaxy S7 Edge
---------	----------------

Samsung	J3PRO
---------	-------

Samsung	J5
---------	----

Samsung	J7
---------	----

Samsung	S8
---------	----

Samsung	S8+
---------	-----

Smartisan	Pro
-----------	-----

VIVO	X9
------	----

XiaoMi	MAX
--------	-----

XiaoMi	MIX
--------	-----

XiaoMi	Note2
--------	-------

XiaoMi	6
--------	---

XiaoMi	Note2
--------	-------

XiaoMi	NOTE4
--------	-------

XiaoMi	Pro
--------	-----

ZTE	Z11
-----	-----

ZTE	Z17
-----	-----